



911-210-10
911-211-10

Additional Instructions

Barcode scanner

IMPORTANT
READ CAREFULLY BEFORE USE
KEEP FOR FUTURE REFERENCE

All rights reserved.

Property of Dürkopp Adler GmbH and protected by copyright. Any reuse of these contents, including extracts, is prohibited without the prior written approval of Dürkopp Adler GmbH.

Copyright © Dürkopp Adler GmbH 2023

1	General information	3
1.1	Components of the kit.....	3
1.2	Barcode types.....	4
2	Assembling the kit.....	5
2.1	Assembling and connecting bracket and scanner	5
2.1.1	Assembling and connecting bracket and barcode scanner (sewing field size 3020)	5
2.1.2	Assembling and connecting bracket and barcode scanner (sewing field size 6055/3020/6020/8055)	7
2.1.3	Assembling and connecting bracket and barcode scanner on machines with a thread burner (911-211 only)	9
2.1.4	Assembling and connecting bracket and barcode scanner on the machine head (911-211 only).....	12
2.2	Laying and connecting the cable to the control	14
2.3	Aligning the barcode scanner and applying the barcode.....	15
2.4	Activating the barcode scanner	16
2.5	Linking the barcode to a seam program	17
2.5.1	Entering the barcode manually	17
2.5.2	Barcode detection.....	21
3	Barcodes (Code 128).....	22

1 General information

These additional instructions describe how to assemble and use the barcode scanner.

1.1 Components of the kit

Check whether the scope of delivery for kit 0911 597574 is correct prior to installation.

Part number	Quantity	Description
9835 400083	1	Scanner, bar code 1D
0911 568000	1	Bracket
0911 568010	1	Bracket
0911 568020	1	Bracket
0911 568030	1	Bracket
9202 001667	2	Screw M3x8
9203 003737	3	Screw M4x25
9231 110035	2	Hexagon nuts
9330 200077	2	Washer A3.2
9840 121002	4	Cable tie
9850 001518	1	Level converter
9204 200747	2	Screw M2, 5x6-H
1001 009243	2	Washer 4.3x10x1.5
9202 002077	2	Screw M4x10
9202 002068	2	Screw M4x8
0791 911718 EN	1	Additional Instructions

1.2 Barcode types

The following types of barcodes can be read using the barcode scanner:

- Code 128
- UCC EAN 128
- Code 39
- Code bar
- Code 93

These barcode types can be created with freeware software.



Important

The barcode must be composed of 3 to 10 bars.

However, you can also use the barcodes provided on the last page.

2 Assembling the kit

WARNING



Risk of injury!

Crushing or electric shock possible.


Switch off the machine before assembling the kit.

2.1 Assembling and connecting bracket and scanner

2.1.1 Assembling and connecting bracket and barcode scanner (sewing field size 3020)

Assembling bracket and barcode scanner

Fig. 1: Assembling bracket and barcode scanner



(1) - Screws

(2) - Bracket (part number 0911 568000)

(3) - Barcode scanner




To assemble the bracket for sewing field size 3020:

1. Assemble the barcode scanner (3) to the bracket (2) using 2 screws (M1.5x5).
2. Tighten the bracket (2) to the transport carriage using the screws (1) (M3x5).

Laying and connecting the cable of the barcode scanner

Fig. 2: Laying and connecting the cable of the barcode scanner



(1) - Energy chain

(2) - Cable

(3) - 17-pin plug of the control

(4) - 17-pin plug of the barcode scanner




To lay and connect the cable of the barcode scanner:

1. Attach the cable (2) along the energy chain (1).
2. Connect the 17-pin plug of the barcode scanner (4) with the 17-pin plug of the control (3).

2.1.2 Assembling and connecting bracket and barcode scanner (sewing field size 6055/3020/6020/8055)

Assembling bracket and barcode scanner

Fig. 3: Assembling bracket and barcode scanner



(1) - Screw

(2) - Bracket (part number 0911 568010)

(3) - Barcode scanner




To assemble the bracket for sewing field size 6055/3020/6020/8055:

1. Assemble the barcode scanner (3) to the bracket (2) using 2 screws (M1.5x5).
2. Tighten the bracket (2) to the transport carriage using the screw (1).

Laying and connecting the cable of the barcode scanner

Fig. 4: Laying and connecting the cable of the barcode scanner



(1) - Energy chain

(2) - Cable

(3) - 17-pin plug of the control

(4) - 17-pin plug of the barcode scanner



To lay and connect the cable of the barcode scanner:


1. Attach the cable (2) along the energy chain (1).
2. Connect the 17-pin plug of the barcode scanner (4) with the 17-pin plug of the control (3).

2.1.3 Assembling and connecting bracket and barcode scanner on machines with a thread burner (911-211 only)

If you have assembled a thread burner, you can assemble a stationary barcode scanner behind the thread burner.

Assembling bracket and barcode scanner

Fig. 5: Assembling bracket and barcode scanner (1)



- | | |
|---|-----------------------|
| (1) - Carrier plate | (4) - Barcode scanner |
| (2) - Bracket (part number 0911 568030) | (5) - Screws |
| (3) - Plate | |



To assemble the bracket to machines with a thread burner:


1. Assemble the barcode scanner (4) to the bracket (2) using 2 screws (M1.5x5).
2. Loosen the screws (5).
3. Remove the plate (3).
4. Assemble the bracket (2) to the carrier plate (1).



Important

If the two threaded holes (6) do not exist in the carrier plate (7), they need to be made as shown in the diagram below.

Fig. 6: Assembling bracket and barcode scanner (2)




(6) - Threaded holes

(7) - Carrier plate

Laying and connecting the cable of the barcode scanner

Fig. 7: Laying and connecting the cable of the barcode scanner



(1) - Cover
(2) - Cables

(3) - Cover




To lay and connect the cable of the barcode scanner:

1. Disassemble covers (1) and (4).
2. Lay the cable through the machine head and under the tabletop so that it runs parallel to the other cables (2).
3. Attach the cable to the wiring harness (3) using cable ties.
4. Connect the 17-pin plug of the barcode scanner with the 17-pin plug of the control.
5. Assemble covers (1) and (4).

2.1.4 Assembling and connecting bracket and barcode scanner on the machine head (911-211 only)

If you did not assemble a thread burner, you can assemble a stationary barcode scanner to the machine head.

Fig. 8: Assembling bracket and barcode scanner to the machine head



(1) - Eye protection
(2) - Barcode scanner

(3) - Bracket (part number 911 568020)
(4) - Screws




To assemble the bracket to the machine head:

1. Assemble the barcode scanner (2) to the bracket (4) using 2 screws (M1.5x5).
2. Tighten the bracket (4) to the machine head using the screws (3). If necessary, adjust the alignment of the barcode scanner (2) by bending the bracket (4).

Laying and connecting the cable of the barcode scanner

Fig. 9: Laying and connecting the cable of the barcode scanner



(1) - Cover
(2) - Cables

(3) - Cable harness
(4) - Cover




To lay and connect the cable of the barcode scanner:

1. Disassemble covers (1) and (4).
2. Lay the cable through the machine head and under the tabletop so that it runs parallel to the other cables (2).
3. Attach the cable to the wiring harness (3) using cable ties.
4. Connect the 17-pin plug of the barcode scanner with the 17-pin plug of the control.
5. Assemble covers (1) and (4).

2.2 Laying and connecting the cable to the control

Fig. 10: Laying and connecting the cable to the control



- (1) - Scanner cable
- (2) - Tabletop

- (3) - Plug



To lay and connect the cable to the control:

1. Feed the scanner cable (1) through the tabletop (2).
2. Insert the plug (3) with the level converter into slot **X23 (BDE)** on the control and secure it using the screws.


2.3 Aligning the barcode scanner and applying the barcode



To align the barcode scanner:

1. Loosen the screws of the bracket.
2. Set the bracket so that the light beam of the barcode scanner hits the frame of the transfer plate.
3. Tighten the screws of the bracket.

Fig. 11: Applying the barcode



(1) - Barcode



To apply the barcode:

1. Apply the generated barcode (1) to the transfer plate in such a way that the light beam of the barcode scanner fully captures the code.

2.4 Activating the barcode scanner




To activate the barcode scanner:




1. Switch on the machine.
 2. Press the menu items *Edit > Machine parameters*.
 3. Enter the code: 25483.
- ↳ The window for selecting the machine parameter group appears.

Fig. 12: Activating the barcode scanner (1)




4. Press the parameter group *Configuration* .

Fig. 13: Activating the barcode scanner (2)



5. Press *Options* .

Fig. 14: Activating the barcode scanner (3)




6. Press *Barcode reader* to switch on the barcode scanner.

2.5 Linking the barcode to a seam program

2.5.1 Entering the barcode manually

Assigning a barcode ID

Fig. 15: Assigning a barcode ID (1)



To assign a barcode ID:



1. Press the menu items *Edit > Seam program > Sewing parameters*.
2. Press the parameter group *Configuration* .

Fig. 16: Assigning a barcode ID (2)




3. Press *ID* .

Fig. 17: Assigning a barcode ID (3)



4. Enter the ID code (no more than 10 characters).
The ID must match the barcode.


Selecting barcode mode



To select barcode mode:


1. Press the menu items *Edit > Machine parameters*.
- ↳ The window for selecting the machine parameter group appears.

Fig. 18: Selecting barcode mode (1)



2. Press the parameter group *Configuration* .


Fig. 19: Selecting barcode mode (2)



3. Press *Barcode mode* .

- ↳ The following 2 options are available.
- **Manually:** The machine checks whether the inserted clamp matches the entered seam program. If the clamp is correct, the machine is ready for sewing. If the clamp is incorrect, an error message will be displayed, and the clamp will have to be replaced.
 - **Automatic:** The machine looks for the seam program that matches the inserted clamp. The machine is ready for sewing once the seam program has been selected.

Fig. 20: Selecting barcode mode (3)



4. Select the desired mode.

2.5.2 Barcode detection



Information

Setting up barcode detection requires an existing seam program that has not been assigned a barcode ID yet.



To set up barcode detection:


1. Apply a new barcode to the transfer plate.



2. Scan the barcode.

↳ The display switches to *Automatic Clamp Change*.

Fig. 21: Barcode detection (1)




3. Press the desired seam program.

↳ The selected seam program is highlighted with a dark background.

4. Press *Link barcode to seam and start*.

↳ The display switches to the seam program.
The sewing process can be started.

Fig. 22: Barcode detection (2)



↳ From now on, this seam program cannot be launched unless the matching bar code was scanned.

3 Barcodes (Code 128)



911_001



911_002



911_003



911_004



911_005



911_006



911_007



911_008



911_009



911_010



911_011



911_012



911_013



911_014



911_015



911_016



911_017



911_018



911_019



911_020



911_021



DÜRKOPP ADLER GmbH
Potsdamer Str. 190
33719 Bielefeld
Germany
Phone: +49 (0) 521 925 00
Email: service@duerkopp-adler.com
www.duerkopp-adler.com